



C05FC

4WD/AWD Range Actuator Position Sensor Circuit Range/Performance

The C05FC code indicates that the control module for the four-wheel-drive or all-wheel-drive system has detected an out-of-range or erratic signal from the range actuator position sensor, which monitors the physical position of the transfer case range fork. The computer expects a specific voltage or signal pattern as the actuator moves between high range, low range, and neutral, but the observed signal does not match the commanded position within the allowed time or voltage window.

SYSTEM Chassis	CODE TYPE Generic (all makes)	SEVERITY Medium	FIX DIFFICULTY Intermediate	AREA Brakes, steering and suspension
--------------------------	---	---------------------------	---------------------------------------	--

Symptoms you may notice

- The four-wheel-drive or all-wheel-drive warning light or service light illuminates on the dashboard.
- The transfer case may fail to shift into or out of low range when the driver presses the selector button.
- The vehicle may remain stuck in high range or default to a neutral state, preventing engagement of any range.
- A grinding or clunking noise may be heard from the transfer case during attempted range changes.
- Often no symptoms besides the warning light, especially if the fault is intermittent or only sets under specific conditions.
- The driver may notice that the range selector indicator flashes or does not match the actual range engaged.

Common causes, most likely first

- 1 A faulty range actuator position sensor, worn or contaminated internally, sending an erratic signal.
- 2 Damaged or corroded wiring and connectors between the position sensor and the control module, including chafed harnesses near the transfer case.
- 3 A binding or mechanically stuck range actuator motor or shift fork, causing the sensor to report a position that does not match the commanded movement.
- 4 Low or incorrect transfer case fluid level, leading to poor lubrication and sluggish actuator response.
- 5 A failing transfer case control module or a software calibration issue that misinterprets the sensor signal.
- 6 A misadjusted or improperly installed position sensor after previous transfer case repairs.
- 7 Water intrusion into the sensor or connector, causing intermittent short or open circuits.



How to diagnose and fix it

- 1 Scan all modules for stored and pending codes, and record freeze-frame data to see the commanded versus actual range position when the fault set.
- 2 Inspect the transfer case fluid level and condition, and top up or replace fluid if it is low or contaminated.
- 3 Visually inspect the position sensor, actuator, and all related wiring and connectors for damage, corrosion, or loose pins.
- 4 Back-probe the position sensor signal wire and compare its voltage to the manufacturer's specification while commanding range changes with a scan tool.
- 5 Check the actuator motor circuit for proper power and ground, and verify that the actuator moves freely when commanded.
- 6 If the sensor signal is out of range but the actuator moves correctly, replace the position sensor and perform a calibration or relearn procedure.
- 7 If the actuator is binding or the motor is weak, repair or replace the actuator assembly, then clear codes and verify proper range engagement through several drive cycles.

Before you replace the transfer case actuator

- A low transfer case fluid level or the wrong fluid type is a commonly overlooked cause of this code because it makes the actuator work harder and slows its response, which the sensor reports as out of range.
- The position sensor can be tested with a simple multimeter by sweeping the range manually, but many technicians replace the entire actuator assembly without first checking the sensor signal, leading to unnecessary expense.
- Intermittent C05FC codes often trace to a chafed wire harness near the transfer case that only shorts when the suspension flexes or the engine moves under load, so a wiggle test while monitoring live data is essential.
- This code does not always mean the sensor has failed; a binding shift fork or a weak actuator motor can cause the sensor to report a position that never matches the command, so mechanical checks must precede electrical parts replacement.
- After any repair, a calibration or relearn procedure is usually required so the control module learns the new sensor's voltage range, and skipping this step will cause the code to return immediately.

Can I keep driving with C05FC?

You can usually drive the vehicle in its current range, but avoid attempting further range changes and do not rely on four-wheel drive or low range until the fault is repaired. If the vehicle is stuck in neutral or the transfer case is making grinding noises, stop driving and have it towed to prevent internal damage.



Tools that help

- OBD-II scan tool with bidirectional control and live data capability
- Digital multimeter with back-probe pins
- Transfer case fluid pump or funnel
- Basic socket and wrench set
- Wire terminal cleaning brush and dielectric grease

Reading C05FC

C	Chassis: brakes, steering and suspension.
0	Generic (SAE) code: it means the same thing on every OBD-II vehicle.
5	Brakes, steering and suspension.
FC	The exact fault within that area.

Often seen with

P1870 Transmission Component Slipping · **C05FB** 4WD/AWD Range Actuator Position Sensor Circuit · **C05FD** 4WD/AWD Range Actuator Position Sensor Circuit Low · **C05FE** 4WD/AWD Range Actuator Position Sensor Circuit High · **U0102** Lost Communication with Transfer Case Control Module

See it working

Watch the animated explainer [How a Wideband Air-Fuel Sensor Works](#) on Auto Veteran to see the parts involved moving.

Full guide, related articles and animations: <https://www.autoveteran.tech/dtc-codes/c05fc/>

