

GENERIC · POWERTRAIN

P0A5B

OBD-II DIAGNOSTIC TROUBLE CODE (DTC)

P0A5B

Generator Current Sensor Circuit Low

P0A5B indicates that the powertrain control module has detected a low voltage signal from the generator current sensor circuit, which typically measures the current flowing to or from the alternator. The computer expects the sensor's output to stay within a specific voltage range, and a low reading means the circuit is below the minimum threshold, potentially due to a wiring fault, poor connection, or sensor failure.

SYSTEM Powertrain	CODE TYPE Generic (all makes)	SEVERITY Medium	FIX DIFFICULTY Intermediate	AREA Hybrid propulsion
---	---	---------------------------------------	---	--

Symptoms you may notice

- Illumination of the battery/charging system warning light or check engine light
- Often no symptoms besides the warning light, especially if the charging system still functions
- Dimming headlights or interior lights, particularly at idle
- Battery that repeatedly goes dead or requires frequent jump starts
- Electrical accessories behaving erratically or shutting down intermittently
- A slight hesitation or rough running if the PCM reduces alternator load to protect the system

Common causes, most likely first

- 1 Damaged or corroded wiring in the generator current sensor circuit, such as a chafed wire or broken connector
- 2 Failed generator current sensor itself, often due to internal electronics or heat damage
- 3 Poor electrical connection at the sensor, battery, or ground points causing high resistance
- 4 Faulty alternator that is not producing the expected current, leading to a low signal from the sensor
- 5 PCM software issue or internal fault in the current sensing circuit
- 6 Aftermarket accessories improperly wired into the charging system, causing abnormal current draw



How to diagnose and fix it

- 1 Perform a visual inspection of the generator current sensor, its connector, and the wiring harness for damage, corrosion, or loose pins
- 2 Check the sensor's reference voltage and ground at the connector with a multimeter to confirm the circuit integrity
- 3 Measure the sensor's output signal voltage while the engine is running and compare it to the manufacturer's specification
- 4 Test the alternator's charging output and battery condition to rule out a charging system fault that could mimic a sensor issue
- 5 Inspect and clean all ground connections related to the charging system, including the engine ground and battery terminals
- 6 If the sensor signal is out of range and wiring is good, replace the generator current sensor and clear the code
- 7 After repairs, clear the diagnostic trouble codes and verify the code does not return during a test drive with electrical loads applied

What a low current sensor signal really means

- A low signal from the generator current sensor often results from a poor ground connection rather than a failed sensor, so always check grounds before replacing parts.
- The code can set intermittently due to a loose battery terminal or corroded ground strap, which may not show up during a simple voltage check.
- Some vehicles use the current sensor to enable regenerative braking or smart charging, so a fault can affect fuel economy and battery longevity even if the alternator still charges.
- A failing alternator diode can cause abnormal current pulses that the sensor interprets as a low signal, leading to misdiagnosis of the sensor itself.
- Aftermarket high-power audio or lighting accessories can draw excessive current and trigger this code if the sensor's range is exceeded, so verify no unauthorized modifications exist.

Can I keep driving with P0A5B?

You can usually drive the vehicle short distances to a repair shop, but avoid long trips or heavy electrical loads because the charging system may not be properly monitored and could fail without warning. If the battery warning light is on or the battery voltage gauge is low, stop driving and seek assistance to prevent a breakdown.



Tools that help

- OBD-II scan tool with live data capability
- Digital multimeter
- Wiring diagram for the charging system
- Basic hand tools for connector and sensor removal
- Battery load tester

Reading P0A5B

P	Powertrain: engine, transmission and emissions.
0	Generic (SAE) code: it means the same thing on every OBD-II vehicle.
A	Hybrid propulsion.
5B	The exact fault within that area.

Often seen with

P0562 System Voltage Low · **P0563** System Voltage High · **P0A5C** Generator Current Sensor Circuit High · **P0A5D** Drive Motor A Phase U Current · **P2500** Generator Lamp/L-Terminal Circuit Low

See it working

Watch the animated explainer [How a Wideband Air-Fuel Sensor Works](#) on Auto Veteran to see the parts involved moving.

Full guide, related articles and animations: <https://www.autoveteran.tech/dtc-codes/p0a5b/>

