

GENERIC · POWERTRAIN

P2075

OBD-II DIAGNOSTIC TROUBLE CODE (DTC)

P2075

Intake Manifold Tuning (IMT) Valve Position Sensor/Switch Circuit

P2075 indicates that the powertrain control module (PCM) has detected an abnormal signal from the intake manifold tuning (IMT) valve position sensor or switch circuit. The IMT valve alters intake runner length to optimize airflow at different engine speeds, and the PCM expects a specific voltage or switch state that does not match commanded position.

SYSTEM Powertrain	CODE TYPE Generic (all makes)	SEVERITY Medium	FIX DIFFICULTY Intermediate	AREA Fuel and air metering and auxiliary emission controls
----------------------	----------------------------------	--------------------	--------------------------------	---

Symptoms you may notice

- Illumination of the check engine light, often with no other noticeable symptoms
- Slight hesitation or stumble during acceleration, especially at mid-range engine speeds
- Reduced engine power or sluggish throttle response
- Rough idle or unstable idle quality
- Poor fuel economy in some cases
- In rare instances, a noticeable rattle or ticking from the intake manifold area

Common causes, most likely first

- 1 Faulty IMT valve position sensor or switch
- 2 Damaged, disconnected, or corroded wiring in the sensor circuit
- 3 Sticking or mechanically binding IMT valve actuator
- 4 Vacuum leak or faulty vacuum supply to the IMT actuator (on vacuum-operated systems)
- 5 Failed IMT valve solenoid or control module
- 6 PCM software issue or internal fault (less common)



How to diagnose and fix it

- 1 Perform a visual inspection of the IMT valve, sensor, and associated wiring for obvious damage or disconnection
- 2 Use a scan tool to command the IMT valve through its full range and observe the position sensor voltage or switch state for smooth operation
- 3 Check the sensor reference voltage and ground circuits with a digital multimeter to rule out wiring faults
- 4 Test the IMT valve actuator for mechanical freedom and correct vacuum or electrical operation
- 5 Compare live sensor data to manufacturer specifications and inspect for vacuum leaks if applicable
- 6 Replace the faulty IMT valve position sensor, switch, or complete IMT valve assembly as needed
- 7 Clear the diagnostic trouble code and verify the repair by completing a drive cycle

What the IMT valve code really means

- A stuck-open or stuck-closed IMT valve often causes no driveability symptoms, so the code may be the only clue.
Wiring harness chafing near the intake manifold is a common cause that is frequently overlooked during diagnosis.
- On some engines, a dirty or carbon-fouled IMT valve can mimic a sensor failure, so cleaning the valve may resolve the code.
- The PCM may set P2075 if the sensor signal is plausible but does not match the commanded position during a self-test, not just for open or short circuits.
Replacing the sensor without checking the actuator mechanism can lead to a repeat code if the valve itself is binding.

Can I keep driving with P2075?

You can generally continue driving with P2075, but avoid aggressive acceleration or heavy load until the fault is repaired, as the engine may not deliver full performance and fuel economy could suffer.

Tools that help

- OBD-II scan tool with live data and bidirectional control
- Digital multimeter
- Vacuum pump and gauge (for vacuum-operated systems)
- Basic hand tools (sockets, wrenches, screwdrivers)
- Wiring diagram and service information for the specific vehicle



Reading P2075

- P** Powertrain: engine, transmission and emissions.
- 2** Generic (SAE) code: it means the same thing on every OBD-II vehicle.
- 0** Fuel and air metering and auxiliary emission controls.
- 75** The exact fault within that area.

Often seen with

P2004 Intake Manifold Runner Control Stuck Open (Bank 1) · **P2005** Intake Manifold Runner Control Stuck Open (Bank 2) · **P2008** Intake Manifold Runner Control Circuit/Open (Bank 1) · **P2076** Intake Manifold Tuning (IMT) Valve Position Sensor/Switch Ci · **P2077** Intake Manifold Tuning (IMT) Valve Position Sensor/Switch Ci

See it working

Watch the animated explainer [Four-Stroke Engine Cutaway: Intake to Exhaust](#) on Auto Veteran to see the parts involved moving.

Full guide, related articles and animations: <https://www.autoveteran.tech/dtc-codes/p2075/>

